


# Remote Update Tool for End-User

The Remote Update Tool (End-User) contains mainly three parts; firstly, "Update Tag" intends to be used for customer to update remote flag; secondly, "Update File" can be utilized with the method of secure file transfer, to update file contents inside of ROCKEY6 SMART for end-user; the third one is "Module Manager", applying to define module requirements and download authorization module. To operate the last two parts in the right way, it is necessary to enter the field of "new Tag" and "New Password" with the value obtained from the SW vendor.

## 1. Update Tag


Two steps are required for end-user to handle remote flag update; informing SW vendor against the dongle-related data within the column of "Device Info" by user is in the first place; SW vendor generates "New tag" and "New Password" based on the "Device Info" got from user, and sends them back to end-user; in the end, user write corresponding values on the field of "New tag" and "New Password", and click "Update" buttons to complete the procedure.



## 2. Update File


When user is in need of update, SW vendor first generates "New tag" and "New Password" on basis of device info of end-user, and sends user some files calling for update with the method of secure file transfer; therefore, user should following steps to complete file update such as:

- ✓ Press "Update File" tab of Remote Update Tool of end-user;
- ✓ Add files demanding update into the "File List" one by one;
- ✓ Write corresponding value got from SW vendor into the field of "New tag" and "New Password"
- ✓ Click "Update" button to begin the operation.



### 3. Module Manager

For the purpose of managing module in effect way, first of all, user generates module requirement files for those modules set as required one based on the specific definition from SW vendor; and later user sends a package of data to the SW vendor involving module requirement files and "Device Info" relative to the dongle of user. The SW vendor, therefore, will generate "New tag" and "New password" according to the "Device Info", similarly, generate authorization file in terms of the user requirement, and send them back to the end-user. While receiving them, user can begin updating modules correspondingly.



### 3.1 Define Requirement

Press "Browse" button to select a particular module definition file provided by developer, and choose "Open/Close" operation for different modules in reference of the "FileID List"; finally, clicking "Generate File" button to create a module requirement file, which will be sent to the SW vendor by user.

### 3.2 Download Authorization

SW vendor, in the beginning, generate "New tag" and "New Password" as soon as they got the user information, and generate authorization file based on the requirement file template of user, which will be sent to the user at a later stage. In such way, user may begin remote updating with this authorization

file in hand.

Before downloading authorization, it is a must to write "New tag" and "New Password" into the relevant field of "Update Tag" tab. Check "Download Authorization (A)" and browse to choose a particular file, after that, specify a needed "module authorization file" and click "Update" button to start operation.